

# SLAM SPECIALTIES

Model No. : IMP-6570-F

Made in USA

Front Bag Bracket Kit

Thank you for Purchasing your bracket kit from Slam Specialties

This instruction sheet provides general mounting information for installation of your air bag mounting brackets. Please note chassis and or classic vehicle variance may cause fitment or installation issue that may require some alterations to product for proper fitment and installation. Clearances to chassis spring pockets may be required for air spring fitment / clearance and are sole responsibility of the installer. Cycling of suspension is highly encouraged, be aware of air spring clearance near sharp objects and or other moving components. If you have any questions or concerns, please call 888-352-5225 or 559-348-9038 or e-mail [info@slamspecialties.com](mailto:info@slamspecialties.com)

---

#### Product contents:

(2) IMP_6570_Upper_F bracket	(1) HK_1108 bracket mounting hardware	
(2) IMP_6570_Lower F bracket	(2) 1/2-13 x 8" all thread	(2) 1/2" flat washer
(1) BH_1100 bag hardware	(2) 1/2-13 nut	(2) 1/2" lock washer
(6) 3/8-16 x1 bolt		
(6) 3/8 flat washer		

---

Using a properly sized floor jack & jack stands or vehicle hoist to raise and support the vehicle. Once your vehicle is safe and secure, begin by removing the wheels. Carefully remove the factory coil springs from the vehicle. Removal of the factory bump stop may be needed to avoid possible clearance issues.

Install the proper air fitting into your air bag using thread sealant (Loc-Tite 565 recommended). Using supplied 3/8-16 bolts and washers install the upper mounting bracket to your air bag.

Install the supplied 1/2" all thread onto the upper bag plate. Slide the upper plate and bag assembly into upper spring pocket. Check for clearance around air spring, Note: some trimming around the upper spring pocket maybe nessessary for air bag fitment. With clearance made guide the 1/2" all thread through the spring pocket and shock tower, use supplied hardware to secure assembly to OEM shock tower.

Using the supplied hardware install mount the lower bracket to the air bag. The lower air bag bracket will sit in the lower control arm pocket.

Reverse the steps taken to remove OEM coil spring, Use factory torque specs on all removed hardware. Check air spring for clearance, avoid sharp or moving objects that may encounter the air bag. Inspect while both dis-inflated and inflated, use a spray bottle with a water/soap solution and spray fitting and line for air leaks.

Congratulations! You have completed the installation of your rear air bags and brackets.